

Nov 20, 2019

Austin, Texas

Qualcomm

# Object Detection @ 1mW

Enabling

*Always-On Computer Vision*

at the Edge

**Ravishankar Sivalingam**

Sr. Staff Engineer

Qualcomm® Artificial Intelligence (AI) Research

Qualcomm Technologies, Inc.

# Outline

1. Background
2. Use Cases
3. Our Approach
4. Product
5. Future

# Goal


## Ultra-low power always-on computer vision

- Ultra-low power for always-on: **System power** less than 1mA on standard lithium cell
- Low latency with typical frame rate of 1-30 fps
- Computer Vision: Insight and information from sensor

## Historically

- Image sensor takes 10mW to Ws
- Image processing takes 100mW to Ws

# Vision will enhance many use cases across numerous verticals




## Smartphone

- Face-based auto-wake and auto-sleep
- Always-on trigger for other use cases
- Always-on trigger for iris authentication (removes multiple steps and user initiation)



## Smart watch

- Face-based auto-wake and auto-sleep
- Always-on gestures



## Tablets

- Simple gaze tracking for advertising attribution
- Improved landscape/portrait screen orientation



## Virtual reality

- Low power gaze tracking (foveated rendering)
- Low power visual odometry for 6 DoF



## 'Intelligent' occupancy trigger

- Distinguish humans from other objects
- Add data layer to trigger: How many? Where?
- Trigger on particular events or objects



## 'Intelligent' interactivity trigger

- Face detection as a trigger for interactivity
- Smart appliance can react when a user approaches to engage it




## Standalone intelligent data sensor

- Heat maps of how a space is occupied
- Privacy advantages - data only, no images captured

# Our always-on vision research and innovation

Integrated vision sensor & processor,  
independent of main processor



# Supports various human detection cases



Half body




Full body



3/4 body




Change Detection




Multiple orientation

# Support visual detection across a broad set of use cases



Simple Gesture (e.g. Left-Right-Left)




2-D Marker Or Logo, 3D Rigid Body (Toys)




Analytic use case:  
(1) Shelf Status  
(2) Customer Engagement

# Successful detection in challenging light scenarios

- Detection scenario at distance and low light is challenging
- Model and algorithm must be resilient to these scenarios
- Sensor also sensitive to 850 nm IR



Face at low light (0.1 lux)



Face detection low light indoor at 768us



Full Body 20 ft 3 lux



Full Body in direct sunlight



# What needs to be done for Always-on Computer Vision

| Our Approach   | Traditional Approach                      |
|--|---|
| Image itself is secondary to information                 | Image quality paramount                   |
| Monochrome works in most cases. $\leq 8$ -bit sufficient | Color & wide bit-depth preferred          |
| Focus can be good enough in most cases                   | Focus, autofocus, Bokeh important         |
| Adequate pixel count for applicable distance             | Higher pixel count                        |
| System power optimized including sensor                  | Sensor & algorithm/model often split      |
| Images shot in challenging lighting                      | Camera & subject posed for best image     |
| Inference is heavily weighted                            | Balance between training & inference time |
| Algorithms redesigned with memory & power in mind        | Built upon available technologies         |
| Metrics may be event-based                               | Typical metric is frame-based             |

Count your pennies, every savings in power adds up

# Our System Approach for Always-on Computer Vision

- Favor algorithms with adaptive compute
  - Only perform computer vision when image/area has changed
  - Run light weight algorithms first
  - Favor algorithms/models with content adaptive capabilities
  - Stop when there is enough information:  
many application only needs to know the presence of 1 object vs. all objects
- Simplify
  - Often easier to run models at different scales than resizing images
  - Optimize brightness to favor detection
- Optimize the entire system end-to-end
  - Use low power sensor
  - Optimize IO
  - Move algorithms to HW when possible
  - Keep memory close to compute engine


# Product: Qualcomm® QCC112 Chipset

Available commercial product

- Supports many uses at  $\sim 1\text{mW}$ , including chip, sensor, and power management
- Features:
  - Ultra-low-power MCU
  - Streaming Array Processor (SuP)
    - Programmable
    - Can be power collapsed
    - Data bursted with DMA into TCM
  - Embedded PMU
  - Vision Accelerator
  - Custom memory
    - 2X lower dynamic power and 3X lower retention power vs. standard memory cell



# Training Tool: AOCVS (Always-on Computer Vision System) Portal



## AOCVS Data Prepare

DataPrep

This tool helps in augmenting the training dataset for better training and model accuracy

## AOCVS Trainer

Trainer

The tool generates a model by training with the input datasets

## AOCVS Bin Converter

Converter

Tool to convert the XML model files to Binary format

## AOCVS Tuner

Tuner

Tool to tune the parameters for a given model for better accuracy

## AOCVS Evaluator

Evaluator

The tool helps in evaluating an input dataset against a model

# Visualization of Results

Show Recent Jobs

Select all Deselect all Delete Jobs Stop Jobs

Search:

| RunID | Date                    | Status    | Algo | Model(s)                    | Input Type               | Config | Results | Edit |
|-------|-------------------------|-----------|------|-----------------------------|--------------------------|--------|---------|------|
| 14    | 2019-09-16 12:50:29.057 | Completed | OD   | circle_10_13_16_model.bin   | File with list of images | Config | Results | Edit |
| 13    | 2019-09-16 12:49:16.328 | Completed | OD   | circle_10_13_16_model.bin   | File with list of images | Config | Results | Edit |
| 12    | 2019-09-05 10:29:54.975 | Completed | OD   | fullbody_model.bin          | List of images           | Config | Results | Edit |
| 11    | 2019-09-05 10:29:21.068 | Completed | OD   | fullbody_model.bin          | List of images           | Config | Results | Edit |
| 10    | 2019-09-05 10:28:41.532 | Completed | OD   | face_model.bin              | List of images           | Config | Results | Edit |
| 9     | 2019-09-05 10:27:50.489 | Completed | OD   | face_model.bin              | List of images           | Config | Results | Edit |
| 8     | 2019-09-05 10:20:05.618 | Completed | OD   | face_model.bin              | Video file               | Config | Results | Edit |
| 7     | 2019-09-05 08:55:10.470 | Completed | OD   | circle_pattern_10_13_16.bin | File with list of images | Config | Results | Edit |
| 6     | 2019-09-05 08:54:35.959 | Completed | OD   | circle_pattern_10_13_16.bin | File with list of images | Config | Results | Edit |
| 5     | 2019-09-05 08:53:05.583 | Stopped   | OD   | circle_pattern_10_13_16.bin | File with list of images | Config | Results | Edit |

Showing 1 to 10 of 14 entries 1 row selected

Previous 1 2 Next

Run ID :14 (Running) [Evaluator Log](#) [Result CSV](#) [Output tarball](#)

Show  entries Search:

| No. | Processed Frame | Details  |
|-----|-----------------|--|
| 1   |                 | image105_out_14_0.bmp<br>6 detections<br>LBP Count:18089<br><u>Detect #1</u><br>X0 : 58 Y0 : 20 W0 : 19 H0 : 19<br>Orientation : 0<br>Score : 11<br><u>Detect #2</u><br>X1 : 94 Y1 : 18 W1 : 21 H1 : 21<br>Orientation : 0<br>Score : 6<br><u>Detect #3</u><br>X2 : 133 Y2 : 17 W2 : 22 H2 : 22<br>Orientation : 0<br>Score : 3<br><u>Detect #4</u><br>X3 : 56 Y3 : 56 W3 : 20 H3 : 20<br>Orientation : 0<br>Score : 9<br><u>Detect #5</u><br>X4 : 94 Y4 : 58 W4 : 21 H4 : 21<br>Orientation : 0<br>Score : 10<br><u>Detect #6</u><br>X5 : 134 Y5 : 59 W5 : 21 H5 : 21<br>Orientation : 0<br>Score : 8 |
| 2   |                 | image11_out_14_1.bmp   |

Showing 1 to 10 of 51 entries

Previous 1 2 3 4 5 6 Next

# Visualization of Key Performance Metric and Compute Tradeoffs

Show Recent Jobs


Select all Deselect all Delete Records Stop Jobs

Search:

| RunID. | Date                    | Status    | Model                       | GT File         | MaxFPPI | Config  |
|--------|-------------------------|-----------|-----------------------------|-----------------|---------|---|
| 6      | 2019-09-16 12:28:12.552 | Completed | circle_10_13_16_model.bin   | tuning_data.txt | 0.05    | <a href="#">Config</a> <a href="#">Results</a> <a href="#">Edit</a> |
| 5      | 2019-09-05 10:23:51.799 | Completed | circle_pattern_10_13_16.bin | tuning_data.txt | 0.05    | <a href="#">Config</a> <a href="#">Results</a> <a href="#">Edit</a> |
| 4      | 2019-09-05 06:50:12.091 | Completed | circle_pattern_10_13_16.bin | tuning_data.txt | 0.05    | <a href="#">Config</a> <a href="#">Results</a> <a href="#">Edit</a> |
| 3      | 2019-09-05 06:49:21.500 | Completed | circle_pattern_10_13_16.bin | tuning_data.txt | 0.05    | <a href="#">Config</a> <a href="#">Results</a> <a href="#">Edit</a> |
| 2      | 2019-09-05 06:46:30.806 | Stopped   | circle_pattern_10_13_16.bin | tuning_data.txt | 0.01    | <a href="#">Config</a> <a href="#">Results</a> <a href="#">Edit</a> |
| 1      | 2019-09-05 06:33:44.624 | Completed | circle_16_20_25.bin         | tuning_data.txt | 0.01    | <a href="#">Config</a> <a href="#">Results</a> <a href="#">Edit</a> |

Showing 1 to 6 of 6 entries 1 row selected

Previous **1** Next






# Resources

- <https://www.qualcomm.com/invention/artificial-intelligence>
- Contact us at [CVM@qti.qualcomm.com](mailto:CVM@qti.qualcomm.com) for developing new use cases and hardware evaluation for your products



# Thank you!

Follow us on:   

For more information, visit us at:

[www.qualcomm.com](http://www.qualcomm.com) & [www.qualcomm.com/blog](http://www.qualcomm.com/blog)

Nothing in these materials is an offer to sell any of the components or devices referenced herein.

©2019 Qualcomm Technologies, Inc. and/or its affiliated companies. All Rights Reserved.

Qualcomm and Snapdragon are trademarks of Qualcomm Incorporated, registered in the United States and other countries. Other products and brand names may be trademarks or registered trademarks of their respective owners.

References in this presentation to “Qualcomm” may mean Qualcomm Incorporated, Qualcomm Technologies, Inc., and/or other subsidiaries or business units within the Qualcomm corporate structure, as applicable. Qualcomm Incorporated includes Qualcomm’s licensing business, QTL, and the vast majority of its patent portfolio. Qualcomm Technologies, Inc., a wholly-owned subsidiary of Qualcomm Incorporated, operates, along with its subsidiaries, substantially all of Qualcomm’s engineering, research and development functions, and substantially all of its product and services businesses, including its semiconductor business, QCT.